



# Basic Electrical Technology

[ELE 1051]

Three Phase AC Circuits

L24 – Power Associated with Three Phase System

# **Topics Covered**



Power in 3 phase system: active, reactive and apparent. Power measurement

# Three Phase Power



#### **I. Star Connected Load**

#### Complex Power,


$$S = V_{R'O}I_R^* + V_{Y'O}I_Y^* + V_{B'O}I_B^*$$

#### Active Power,

$$P = V_{R'O} I_R Cos \angle (V_{R'O} \& I_R) + V_{Y'O} I_Y Cos \angle (V_{Y'O} \& I_Y) + V_{R'O} I_B Cos \angle (V_{R'O} \& I_B)$$

#### Reactive Power,

$$Q = V_{R'O} I_R Sin \angle (V_{R'O} \& I_R) + V_{Y'O} I_Y Sin \angle (V_{Y'O} \& I_Y) + V_{B'O} I_B Sin \angle (V_{B'O} \& I_B)$$



#### For Balanced Load,

Complex Power,  $S = \sqrt{3} V_L I_L^*$ 

Active Power,  $P = \sqrt{3} V_L I_L Cos \angle \pm \theta$ 

Reactive Power,  $Q = \sqrt{3} V_L I_L Sin \angle \pm \theta$ 

Apparent Power,  $S = \sqrt{3} V_L I_L$ 

### Three Phase Power...



#### 2. Delta Connected Load

#### Complex Power,


$$S = V_{RY} I_{R'Y'}^{*} + V_{YB} I_{Y'B'}^{*} + V_{BR} I_{B'R'}^{*}$$

#### Active Power,

$$P = V_{RY} I_{R'Y'} Cos \angle (V_{RY} \& I_{RY})$$

$$+ V_{YB} I_{Y'B'} Cos \angle (V_{YB} \& I_{YB})$$

$$+ V_{BR} I_{B'R'} Cos \angle (V_{BR} \& I_{BR})$$



#### Reactive Power,

$$Q = V_{RY} I_{R'Y'} Sin \angle (V_{RY} \& I_{RY})$$

$$+ V_{YB} I_{Y'B'} Sin \angle (V_{YB} \& I_{YB})$$

$$+ V_{BR} I_{R'R'} Sin \angle (V_{BR} \& I_{BR})$$

#### For Balanced Load,

Complex Power,  $S = 3 V_{ph} I_{ph}^*$ 

Active Power,  $P = \sqrt{3} V_L I_L Cos \angle \pm \theta$ 

Reactive Power,  $Q = \sqrt{3} V_L I_L Sin \angle \pm \theta$ 

Apparent Power,  $S = \sqrt{3} V_L I_L$ 

### Exercise-I



A balanced star connected load of  $8+j6\ \Omega$  per phase is connected to a 3 phase, 415V supply. Find the line currents, power factor, power, reactive volt amperes and total volt amperes.


## Exercise-2



A star connected load is supplied from a symmetrical three phase, 440V system. The branch impedances of the load are  $Z_R = 5 \angle 30^\circ \Omega$ ,  $Z_Y = 10 \angle 45^\circ \Omega$ ,  $Z_B = 10 \angle 60^\circ \Omega$ . Find the active power supplied by the source.



Power is measured using Wattmeter



It has a current coil connected in series & Potential coil connected in parallel



#### I. Balanced Load (Star Connected) using I Wattmeter

#### Wattmeter Reading,


$$W_1 = V_{R'O} I_R Cos \angle (V_{R'O} \& I_R)$$
$$= V_{Ph} I_{Ph} Cos \theta$$

#### Total active power consumed,

$$= 3 \times W_1$$

$$= 3 \times V_{Ph} I_{Ph} Cos\theta$$

$$= \sqrt{3} \times V_L I_L Cos\theta$$





#### 2. Balanced Load (Delta Connected) using I Wattmeter

#### Wattmeter Reading,


$$W_1 = V_{R'Y'} I_{R'Y'} Cos \angle (V_{R'Y'} \& I_{R'Y'})$$
$$= V_L I_{Ph} Cos \theta$$

#### Total active power consumed,

$$= 3 \times W_1$$

$$= 3 \times V_L I_{Ph} Cos\theta$$

$$= \sqrt{3} \times V_L I_L Cos\theta$$





#### 3. Star Connected Load using 2 Wattmeter's

#### Wattmeter Reading,

$$W_1 = v_{RY} i_R = (v_{R'O} - v_{Y'O}) i_R$$

$$W_2 = v_{BY} i_B = (v_{B'O} - v_{Y'O}) i_B$$


#### Total Active Power,

$$= W_1 + W_2$$

$$= (v_{R'O} - v_{Y'O}) i_R + (v_{B'O} - v_{Y'O}) i_B$$

$$= v_{R'O} i_R - v_{Y'O} (i_R + i_B) + v_{B'O} i_B$$

$$= v_{R'O} i_R + v_{Y'O} i_Y + v_{B'O} i_B$$
 Since,  $i_R + i_Y + i_B = 0$ 





#### 4. Balanced Load (Star Connected) using 2 Wattmeter's

#### Wattmeter Reading,

$$W_{1} = V_{RY} I_{R} Cos \angle (V_{RY} \& I_{R})$$

$$= V_{L} I_{L} Cos(30^{\circ} + \theta)$$

$$W_{2} = V_{BY} I_{B} Cos \angle (V_{BY} \& I_{B})$$


$$= V_{L} I_{L} Cos(30^{\circ} - \theta)$$

#### Total active power consumed,

$$P = W_1 + W_2$$

$$= V_L I_L \cos(30^\circ + \theta) + V_L I_L \cos(30^\circ - \theta)$$

$$= \sqrt{3} \times V_L I_L \cos\theta$$



# Meas. of 3 Ph. Active Power...



Summation of two wattmeters,

$$W_1 + W_2 = \sqrt{3} \times V_L \times I_L \times Cos \theta$$

Difference in the reading of two wattmeters,

$$W_2 - W_1 = V_L \times I_L \times Sin \theta$$

Hence,

$$\frac{W_2 - W_1}{W_2 + W_1} = \frac{\sin \theta}{\sqrt{3} \times \cos \theta}$$

$$\theta = \tan^{-1} \left[ \sqrt{3} \times \frac{W_2 - W_1}{W_2 + W_1} \right]$$

Power factor of the Balanced Load =  $Cos\theta = Cos \left\{ tan^{-1} \left[ \sqrt{3} \times \frac{W_2 - W_1}{W_2 + W_1} \right] \right\}$ 

### Exercise-3



Three identical impedances of (8+j6)  $\Omega$  are connected in delta across a symmetrical 3 phase, 3 wire 400 V system. Calculate the power factor using wattmeter readings.

## Exercise-4



Three loads  $Z_R = 5 \angle 30^{\circ} \Omega$ ,  $Z_Y = 10 \angle 45^{\circ} \Omega$ ,  $Z_B = 10 \angle 60^{\circ} \Omega$  are connected in Star to R,Y and B Phase respectively. The current coils of the two wattmeters are connected in R &Y lines. If the supply voltage is 415V, 50 Hz, determine the reading of the two wattmeters. Assume the phase sequence is RBY.



# Summary



Measurement of Active Power for a three phase Star/Delta connected balanced/unbalanced load can be performed by using two wattmeters.

For a balanced Load, the Load Power factor can be measured by using one or two wattmeter method.

Measurement of power for a balanced Star/Delta load can be performed using one wattmeter.